## **Topic:** How to install a 7120 for air only

## Parts included in the kit:

1 ea Shut Off Block

1 ea 0100, 1/8 MPT x 3/8 Compression Tube

1 ea 0053, 1/4 Poly x 1/8 MPT

1 ea 0099, Pipe Plug Hex Head

1 ea 0074-1, 10-32 x 1/16 Barb

1 ea 0073-1, 10-32 Plug

2 ea 0072-1 Plastic Washer

2 ea 0071-1, 1/8 Clamp Sleeve





Recommended tools: 7/16 Wrench, 3/16 Hex Wrench, 1/4 Nut Drive & Teflon Tape or Pipe Sealant

Install included parts as shown. Use teflon tape or pipe thread sealant on all brass fittings.







